

#750-BAK BEACH FIRE ACCENT KIT

For use with model #CLW-50

NOTE: Rock numbers are located on the bottom of each accent piece. Refer to the following instructions and illustration for proper accent piece placement. Your components may look different than the ones shown.

NOTE: Log and rock pieces may be moved or removed to prevent potential sooting. Do not set any accent piece on top of the burner tube shadow.

CAUTION: Do not set accent media directly on top of burner ports. Do not block pilot assembly. This could cause a potentially hazardous situation.

Kit Components:

(10) Accent Rocks

(7) Beach Fire Log Accent Pieces

1. Install an even layer of your chosen media across the whole burner.
2. Install an even layer of media across the front and rear perimeter
3. Place the beach fire log accent pieces as shown.
4. Place rocks as shown.

